## **Seed feed distribution**

Plugs needed for the seed feed syst:

181712 8 (2 row shut off)

Note! Set tramline to disabled!

## Spirit 400

Plug set up 2 open and 2 closed CC-500 mm





