

Seed feed distribution

Spirit 800



Plugs needed for the seed feed syst:

185961 2 (1 row shut off)
 181712 20 (2 row shut off)


Settings:
 Machine width: 8,25 meter??

Note! Set tramline to disabled!
 Note! The plugging differs between the heads!

Plug set up
 375 mm



= Change the hoses on the coulters!




Left marker



4,31 m

Right marker



4,31 m