

Seed feed distribution


Spirit 800

Plugs needed for the seed feed syst:

181712 16 (2 row shut off)

Note! Set tramline to disabled!

Plug set up
2 rows opened and 2 closed.
(c-c = 500 mm)



 = Change the hoses on the coulters!

